

Router login (Open Browser type 192.168.1.1 enter)

Not secure | 192.168.1.1

Browser type 192.168.1.1

p-1

MERCUSYS MW325R

Basic

Advanced

Log out



Device Management

Connected Devices:2



Network

Connection Type:PPPoE



Wireless

SSID:Islam

Connected Devices 2

Blocked Devices 0

Device	Rate	Upstream	Downstream	Block
 DESKTOP-U205... IP 192.168.1.101	 ↑ 10.2 KB/s ↓ 9.4 KB/s			Host
 HUAWEI_Y6_Pr... IP 192.168.1.100	 ↑ 13.3 KB/s ↓ 268.1 KB/s			

P-2

MERCUSYS MW325R

Basic

Advanced

Log out



Device Management

Connected Devices:2



Network

Connection Type:PPPoE



Wireless

SSID:Islam

Connection Type

PPPoE

Username

C02030711

PPoE username

Password

....

PPoE passowrd

IP Address

10.99.8.105

DNS Server

103.115.24.10 , 8.8.8.8



Select (Save)



Device Management
Connected Devices:2



Network
Connection Type:PPPoE



Wireless
SSID:Islam

Wireless

ON

SSID Islam

Wifi name

Password 100%true

Wifi password



Save

select (Save)

If need select (Advanced)



Network

- WAN Settings
- LAN Settings
- IPTV
- MAC Address Settings
- DHCP Server
- IP & MAC Binding



Wireless



Network Control



Advanced Users



System Tools



Quick Setup

WAN Settings

Connected ?

Connection Type

PPPoE

Username

C02030711

PPoE username

Password

....

PPoE passowrd

IP Address 10.99.8.105

DNS Server 103.115.24.10, 8.8.8.8



Disconnect



Save

Select (Save)

Secondary Connection

☒ None☐ Dynamic IP☐ Static IP

P-5

MERCUSYS MW325R

Basic

Advanced

Log out

If need select (Advanced)



Network



Wireless



Host Network

Guest Network

WDS Bridging



Network Control



Advanced Users



System Tools



Quick Setup

Host Network ON

SSID

Islam

Wifi name

☒ Enable SSID Broadcast

Password

100%true

Wifi password

Security

Channel

Auto

Mode

11bgn mixed

Channel Width

Auto

Transmit Power

High

☐ AP Isolation

Save

select (Save)

P-6

MERCUSYS MW325R

Basic

Advanced

Log out



Network



Wireless



Network Control



Advanced Users



System Tools



Web Management

Time Settings

Firmware Upgrade

Factory Default Restore

Backup & Restore

Reboot

Change Login Password

Diagnostic Tools

System Log



Quick Setup

Local Management



Local Management

Allow all local devices.



Save

Remote Management



Remote Management

Allow all remote devices.

Select

Port

8989

8080/8989



Save

Save



Network



Wireless



Network Control



Advanced Users



System Tools

Select

Web Management

Time Settings

Firmware Upgrade

Factory Default Restore

Backup & Restore



Reboot

Change Login Password

Diagnostic Tools

System Log



Quick Setup

Reboot

Reboot

Select (Reboot)

Click the button to reboot this device.